

# String & Cable Reference Guide

Crossbow Model	Strings	String Twists	Cables	Cable Twists
HuntsMan 1994-1997	HCA-117	13	Upgrade Required	13 (after upgrade)
HuntsMan 1998	HCA-117	13	HCA-126	Steel (no twists)
HuntMaster (w/o yokes) 1994-1995	HCA-115 or HCA-115C	13	Upgrade Required	13 (after upgrade)
HuntMaster (w/yokes) 1995-1997	HCA-115	13	HCA-122	13
HuntMaster TL-4 1998	HCA-115 or HCA-115C	13	HCA-124 or HCA-124C	13
458 Magnum 1996-1997	HCA-119	13	HCA-124	13
458 Magnum TL-4 1998-1999	HCA-115	13	HCA-124	13
WoodsMan, WoodsMan Plus & WoodsMan SE	HCA-117	13	HCA-126	Steel (no twists)
Slider, Titan TL-7, Titan TL-4, Titan & Titan SE	HCA-117	13	HCA-126	Steel (no twists)
Turbo Extreme & Magnum Extreme	HCA-115 or HCA-115C	13	HCA-124 or HCA-124C	13
Elite, Magnum, Stealth & Turbo X-2	HCA-115 or HCA-115C	13	HCA-124 or HCA-124C	13
Elite Lite & Hybrid Lite	HCA-115 or HCA-115C	13	HCA-124 or HCA-124C	13
Pro Fusion & Pro Slider	HCA-115 or HCA-115C	13	HCA-124 or HCA-124C	13
Pro Elite, Elite QX-4 & QX-4	HCA-115 or HCA-115C	13	HCA-124 or HCA-124C	13
Pro Elite HP, Blazer HP & Lazer HP	HCA-11807	13	HCA-12507	13
Phantom Xtra, Phantom CLS & Shadow CLS	HCA-11607	13	HCA-12307	13*
GT Curve & GT Flex	HCA-12008	18-24	N/A	N/A

Note: When installing cables, twist the bottom yoke (located at the end of each cable) four times.

\*Twist the Phantom and Shadow bottom yokes five times. Doing so will eliminate limb twist when cocking your crossbow.