## INSTALLATION OF LEFT-HAND SAFETY KNOB ON ACUSLIDE SERIES CROSSBOWS

Parts required (photo 1):	
A. 1 (ONE) brass safety knob	
B. 1 (ONE) 6-32 x ¾" socket set screw	
	A B
	Photo 1
<ol> <li>Use a 1/16" Allen wrench to screw the ¾" set screw into the threaded hole in the left side of the trigger box (photo 2).</li> </ol>	
	Photo 2
2. Thread the brass safety knob onto the	
¾" set screw (photo 3).	RECLUIRE AFRONS AFRONS MADE IN U.S.A. 1000655
	Photo 3