

## X Series Stirrup Installation Instructions (HCA-23011)

**NOTE:** This stirrup is a replacement for bolt-on stirrups/bow hangers. It is **NOT** compatible with stirrups/bow hangers that bolt into a riser or SDS block.

Package contents: (Photo 1)

- (1) One Bolt-on stirrup
- (2) Two #10-32x5/8" Button Head Socket Cap Screws (with microsphere patch)

\*Additional tool required: T-25 wrench



Photo 1

1. From the bottom of the crossbow, remove the two foot stirrup screws and the foot stirrup (Photo 2).



Photo 2

2. Position the new foot stirrup over the holes in the riser.
3. Insert the new #10-32x5/8" Button Head Socket Cap Screws and tighten with a T-25 wrench (Photo 3).



Photo 3

**NOTE:** Using the old screws may cause the screws to loosen or fall out.

Top-down view of new foot stirrup installed on the X-Series crossbow (Photo 4).



Photo 4

**!/ \ WARNING:** Do **NOT** place your foot in the stirrup when cocking or de-cocking the crossbow with ACUdraw, ACUdraw Silent, ACUdraw De-Cock, or ACUslide Cocking/De-Cocking devices. If an automated cocking device cord or strap were to break, you will injure your foot.