

Twin-Riser Raised Cheek Comb Instructions (for use with Garmin XERO)

HCA-0072

Package Includes (Photo 1):

One (1) Top Section

One (1) Bottom Section

Two (2) #6-32 x 3/8" Button-head Cap Screws with patch



1. Peel off the existing thin cheek piece material (**Photo 2**).
2. Thoroughly clean the stock where the thin material was removed.
3. Peel the adhesive protective covering off of the new Bottom Section.



4. Place the new Bottom Section in the inset area, in the same direction the original cheek piece was oriented. Then, press down on it to let the adhesive bond to the stock.
5. Position the Top Section on top of the Bottom Section with the narrower portion closest to the butt stock.
6. Insert the two 6-32 x 3/8" Button-head Cap Screws into the holes of the Top Section, then use a 5/64-inch Allen wrench to tighten to the Bottom Section (**Photo 3**).

