AMBIDEXTROUS SIDE-MOUNT QUIVER BRACKET INSTALLATION INSTRUCTIONS

1. The Ambidextrous Side-Mount Quiver Bracket Kit contains the following parts (photo 1):

Side-Mount Quiver Bracket (1) Phillips pan-head machine screws (2)

- The standard TenPoint HX quiver package contains the following mounting parts (photo 2) (if the quiver & parts are currently installed on your crossbow, remove only the quiver, quick disconnect (female) attachment, and the two Phillips pan-head screws then skip to step 5):
 - Quick disconnect (female) attachment with lever (1)
 - Phillips pan-head machine screws (2)
 - Quiver mounting bracket for TenPoint models (1)
 - 7/16-inch Nylock Nuts & 3/4-inch setscrews (pre-assembled at the factory) (2)
 - HX Instant Detach Quiver with quick disconnect (male) attachment (1)
 - Quiver mounting bracket for 6 Point models (1)
 - 5/8-inch socket-head cap screw (1)
 - 7/8-inch socket-head cap screw (1)

These parts in italics are for use on 6 Point Series crossbows only. Call Customer Service at 330-628-9245 if additional information is needed.

- 3. If your quiver mount is not already installed, completely remove the two 1/4-inch setscrews holding the foot stirrup in place (n/a for models with an integrated foot stirrup) (photo 3).
- 4. Place the quiver's metal bracket assembly over the two holes you just removed the setscrews from.

The mounting bracket holes should face forward toward the foot stirrup (see photo 4 for orientation).

First, insert and tighten the two 3/4-inch setscrews (with Nylock nuts) into the same holes you removed the original setscrews from.

Then, tighten the two Nylock nuts until the quiver mounting bracket is secure. Use a 7/16-inch open-ended wrench to tighten.

Note: Do no over-tighten.

- 5. Choose which side you want the quiver located and attach the sidemount quiver bracket to the quiver mounting bracket assembly accordingly (the flanges on the side-mount bracket will be facing down from the bottom of the crossbow). Insert the two Phillips pan-head screws, through the bottom of the side-mount bracket, into the quiver mounting bracket assembly (photo 5).
- 6. Attach the female lever-lock attachment to the opposite end flange with two Phillips pan-head screws (photo 6).
- 7. Insert the HX Instant Detach Quiver with male attachment into the quick disconnect (female) attachment with lever, and lock into place (photo 7).













